

# IRON-ON T-SHIRT TRANSFER APPLICATION INSTRUCTIONS



Enclosed you will find one Plastisol transfer from AGAIN AGAIN. This is suitable for transfer onto your T-shirt or sweatshirt provided that it is made from 100% cotton or 50/50 cotton/polyester. Please follow the procedure outlined below in order that you may get the best from this product. **THIS SHOULD BE CARRIED OUT BY, OR IN THE PRESENCE OF AN ADULT AND WITH A HIGH LEVEL OF CAUTION:-**

- 1) Place the transfer face down over the desired area of the garment.
- 2) Cover transfer area with a sheet of plain paper and apply iron directly onto the paper at a temperature of 175-180 degrees centigrade (this will correspond to the hottest setting on most conventional household hand irons).
- 3) Hold down iron **FIRMLY** for a period of 15 seconds, taking care not to scorch the garment.
- 4) After a cooling period of 60 seconds, carefully peel away backing paper to reveal the AGAIN AGAIN logo.

#### AFTER CARE:-

- 1) Do not iron directly over the image area.
- 2) Wash and iron garment inside out at a cool temperature. Tumble dry. Never dry clean.

